

To create a fake serial port:

```
socat pty,raw,echo=0,link=<port1_name> pty,raw,echo=0,link=<port2_name>
```

From:

<https://robosub.eecs.wsu.edu/wiki/> - **Palouse RoboSub Technical Documentation**

Permanent link:

<https://robosub.eecs.wsu.edu/wiki/cs/socat/start?rev=1475884046>



Last update: **2016/10/07 16:47**