

# Hydrophones

Our hydrophones are a powerful tool for figuring out where we are in the water. Using 4 hydrophones, we can calculate our bearing to the pinger. For details, see [Pinger Bearing](#).

## Testing Procedure

### Materials:

1 tub of water  
1 pinger  
Hydrophone Test Rig

### Test Rig:

1. Pinger at one end of tub
2. Hydrophones at other end of tub
3. If lots of noise in readings observed, can place towels around tub

### Procedure:

1. ssh into the sub
2. roslaunch robosub cobalt.launch
3. rosrunc robosub pinger\_bearing
4. rostopic echo /hydrophones/bearing
5. Manipulate hydrophones & Observe bearing readings

From:

<https://robosub.eecs.wsu.edu/wiki/> - **Palouse RoboSub Technical Documentation**

Permanent link:

<https://robosub.eecs.wsu.edu/wiki/cs/hydrophones/start?rev=1550806789>



Last update: **2019/02/21 19:39**