# **Battery Charging**

# **Charging Menu Controls**



'\_'

Cycles through the charging options for the battery chemistry

'+'

• Should cycle in the opposite direction of '-', but there is a short between it and 'PORT' on this charger.

# 'PORT'

Switch between ports, it will also change battery chemistry

# 'MODE'

- Cycles between the Charging menu, Data View, and Settings Data.
- Inside these options, use '-' to cycle through all the options.

#### 'ENTER'

- A long press (~1 second) starts the charging cycle.
- A short press cycles through the options on the screen, it lets you change the capacity it lets

# **Charging Instructions**

When charging the battery, make sure the settings match that of the battery. For the Tattu, it's a 16000 mAh, 4 Cell (4S), LiPo battery that charges at a maximum of 16 amps. We charge it at 8 amps, because it's easier on the battery and still charges the battery at a fast enough rate.


Plug the battery sensing cable into the appropriate slot (4S for 4 cell).





Plug the battery power connector to the charger.

2024/05/06 11:18 3/3 Battery Charging



Long press Enter to start charging the battery when the correct settings are set on the charging menu.

From:

https://robosub.eecs.wsu.edu/wiki/ - Palouse RoboSub Technical Documentation

Permanent link:

https://robosub.eecs.wsu.edu/wiki/ee/battery/start?rev=1518914945

Last update: 2018/02/17 16:49